

1.4

The diagram illustrates a sequence of actions and a resulting state. The top part shows a hand pointing up at a screen with a downward arrow, followed by an equals sign and a screen with an upward arrow, labeled "= OK". The bottom part shows a hand pointing up at a screen with a downward arrow, followed by an equals sign and a screen with a downward arrow, which then points to a sequence of five screens showing a pattern of X's and symbols (NLNΔΔ) above a timeline with markers 4 and 5.

		PT	IT	PL	CZ	EL
120V-50/60 Hz		Verde / Amarelo	Verde / Giallo	Zielono-żółty	Žlutozelený	κίτρινο/πράσινο
	N 1	Azul	Blu	Niebieski	Modrý	μπλε
	Ph/L 2	Castanho	Marrone	Brazowy	Hnědý	καφέ
		Verde / Amarelo	Verde / Giallo	Zielono-żółty	Žlutozelený	κίτρινο/πράσινο
	N 3	Azul	Blu	Niebieski	Modrý	μπλε
	Ph ▼ 4	Castanho	Marrone	Brazowy	Hnědý	καφέ
	Ph ▲ 5	Preto	Nero	Czarny	Černý	μαύρος
		Amarelo	Giallo	Żółty	Žlutý	κίτρινος
	COM ▼ 6	Amarelo	Giallo	Żółty	Žlutý	κίτρινος
	7	Branco	Bianco	Biały	Bílý	λευκό
		Vert	Verde	Zielony	Zelený	πράσινος
	8	Vert	Verde	Zielony	Zelený	πράσινος

2.2

my 1

1.

>>

2.

3s.

>>



The diagram illustrates the two-step process for setting the my 1 roller blind. Step 1 involves pressing the up arrow, the 'my' button, and the down arrow on the remote control, followed by a downward arrow on the blind. Step 2 involves pressing the up arrow, the 'my' button, and the down arrow on the remote control, followed by an upward arrow on the blind.

my 2

1.    >> 

2.    >> 

3s.    >> 

2.3



PROG 7s.

2s

7s

Diagram illustrating the operation of the remote control:

1. Press the **my** button (indicated by an upward arrow) to select the memory channel.

2. Press the **my** button (indicated by a downward arrow) to store the current channel.

3. Press the **my** button (indicated by a double arrow) to recall the stored channel.

The diagram illustrates the transformation of a variable into a memory location. On the left, a variable 'my' is shown in a box with up and down arrows. An arrow points to the text 'my 2', which is then shown in a box with a downward arrow pointing to a memory location. On the right, the memory location is labeled '3.' and contains the value '5s.'. An arrow points to a box representing memory, with a double-headed vertical arrow indicating the range of memory addresses.

CE Με το παρόν έγγραφο, η Somfy δηλώνει ότι η συσκευή, συμμορφώνεται με τις ουσιαστικές απαιτήσεις και τις λοιπές διατάξεις που σχετίζονται με τις ευρωπαϊκές οδηγίες που ισχύουν για την Ευρώπη. Μια δήλωση συμμόρφωσης διατίθεται στην ιστοσελίδα www.somfy.com/ce.

CE Firma Somfy niniejszym oświadcza, że ten produkt jest zgodny z istotnymi wymaganiami i innymi odpowiednimi postanowieniami dyrektyw Unii Europejskiej dotyczącymi Europy. Deklaracja zgodności jest dostępna pod adresem internetowym www.somfy.com/ce.

CE dašími príslušnými ustanoveniami smernice 1999/5/CE. Prohlášení o shodě naleznete na www.somfy.com/ce. Používaní povolené v EU, CH.

© **CE** Ημε το παρόν έγγραφο, η Somfy δηλώνει ότι η συσκευή, συμμορφώνεται με τις συλλογικές απαιτήσεις και τις λοιπές διατάξεις που σχετίζονται με τις ευρωπαϊκές οδηγίες που ισχύουν για την Ευρώπη. Μια δήλωση συμμόρφωσης διατίθεται στην ιστοσελίδα www.somfy.com/ce.